

4. HEADPHONE BUTTONS AND INTERFACE

- Button-1: Single-click to switch FM radio channel or music in micro-SD card. Long-press of this button turns up the volume.
 - Button-2: Pause & switch between the mode of TF card and the FM signal.
 - Button-3: Single-click to switch FM radio channel or music in TF card. Long-press of this button turns down the volume.
1. For better signal transmission, place the transmitter into an open field without too many other digital devices near it.
 2. When the headphone or the transmitter's battery is low, the signal will be weak. This can reduce the quality of the audio and the volume from the headphone. When this occurs, charge the headphone and/or the transmitter.
 3. If you cannot connect headphone to your digital device or after the connection, there is noise, follow these steps:
 - Ensure the headphone's battery is full and on the status of "on" & "pairing"
 - Ensure the transmitter's battery is full and on the status of "on" Check if the distance between headphone and transmitter is over 20', or if there are obstacles and other digital devices between them.

5. SPECIFICATIONS & FEATURES

901 Wireless Headphone	Descriptions
Color	White/Black
Body Material	Plastic/Vinyl
Stereo	Yes
Headphone Form Factor	Earcup
Sound Output Mode	Stereo
Wireless Range	Up to 20'
Connections	1 x headphone (3.5mm stereo), USB-micro USB, Micro SD card slot, RCA audio cable, wireless transmitter
Battery	Built in rechargeable 300mah lithium battery
Playing time	8-10 hours on a single charge
Recharge time	2-3 hours with LED indicator turning off when fully recharged
Product Weight	8 ounces, shipping weight 2 lbs.
Warranty — from date of purchase	Two-year warranty from date of purchase for school use, church and government facilities

6. WARRANTY

Califone warrants this product to be free from defective material and workmanship for one year from the purchase date. Our "Project Intercept" Customer Satisfaction program will replace defective parts and repair malfunctioning equipment under this warranty when the defect occurs under normal use.

All Damage Claims Must Be Made With the Freight Carrier

Notify the freight carrier immediately if you observe any damage to the shipping carton or product. Repack the unit in the carton and await inspection by the carrier's claim agent. Notify your dealer of the pending freight claim.

Returning Your Unit for Service or Repairs

Should your unit require service, contact our Customer Service Department online at califone.com/techsupport or via email warranty@califone.com or by phone at 800-722-0500 / 818-407-2400 to first obtain an RA (Return Authorization) number before returning it to Califone. The unit must be returned to our factory via prepaid transportation only after the factory issues an RA number, which must be clearly written on the outside of the box.

Califone® International, Inc.
1145 Arroyo Avenue, #A
San Fernando, CA 91340 USA
Toll Free 800.722.0500 | Toll Free Fax 877.402.2248
International Customers call 818.407.2400
or Fax 818.407.2405
califone.com

Califone 901 Wireless Headphone 06/24/2014



Model 901 Wireless Headphone



User Manual

901 Wireless Headphone

Thank you for purchasing the Califone® Model 901 Wireless Headphone.

We encourage you to visit www.califone.com/registration to register your product for its warranty coverage, to sign up to receive our newsletter, download our catalog, and learn more about the complete line of Califone® audio visual products, including portable and installed wireless PA systems, multimedia players and recorders, headphones and headsets, computer peripheral equipment, visual presentation products and language learning materials.

1. IMPORTANT SAFETY INSTRUCTIONS

Before using this product, read the instruction manual for important safety information. Please retain this manual for future reference and warranty information.

Troubleshooting & Servicing

Do not attempt to service or repair the device yourself. Refer all servicing to qualified service personnel. Do not attempt to modify the device in any way. Doing so could invalidate your warranty.

Moisture and heat sources

Do not use this apparatus near water (for example, sinks, baths, pools) or expose it to rain, moisture, dripping or splashing liquids. Do not expose the unit to high temperatures, high humidity or direct sunlight.

Cleaning

When cleaning the device, please use a soft, dry cloth. Never use benzene, paint-thinner, or other chemicals on the device.

Location

Place the device in stable location, so it will not fall causing damage to the device or bodily harm.

Intended use

The product may only be used with the original parts intended for it. The product may only be used in closed and dry rooms. The intended use includes adherence to the specified installation instructions. The manufacturer accepts no liability for damage arising due to improper use.

2. PACKAGE CONTENTS

- Wireless headphone
- Wireless transmitter
- 3.5mm male-female cord
- USB-micro cord
- RCA-3.5mm audio cable
- User Manual

3. PART NAMES AND FUNCTIONS



1. Recessed wiring for student safety
2. Adjustable headband
3. Over ear cushions reduce external ambient noise
4. Foldable
5. Micro SD card slot
6. 3.5mm to connect additional wired listener
7. Buttons for menu, change audio sources, volume
8. Wireless transmitter plugs into any audio source with
9. Micro USB for recharging internal batteries

3. OPERATIONS

1. Turn on the audio source (TV, tablet, PC, or smart phone)
2. Plug the transmitter into the audio source
3. Choose the TV channel, or music or video on the headphone and it will begin to wirelessly receive the audio signal!

